

jura®



WiFi Connect

Instructions for use

Proper use

The WiFi Connect may only be used with specified JURA coffee machines. It provides wireless communication between the coffee machine and various accessories (for compatible devices see jura.com). Use for any other purpose will be deemed improper. JURA cannot accept any responsibility for the consequences of improper use.

WiFi Connect at a glance



- 1 LED: Indicates the status of the WiFi Connect
- 2 Connector: Inserted into the service socket on the coffee machine

Installation

The WiFi Connect must be inserted into the coffee machine's service socket. This is usually on the top or back of the machine, beneath a removable cover. If you don't know where the service socket of your coffee machine is, ask your dealer or visit jura.com.

- ▶ Plug the WiFi Connect into the coffee machine's service socket.

In order for your machines to communicate wirelessly, connect them to a network.

- ▶ Configure the network via J.O.E.® – your JURA app. To do this, enter the network name (SSID) and the password.

LED indicators

- LED does not light up: The coffee machine is switched off; the WiFi Connect is not being supplied with power.
- LED lights up: The wireless connection between the WiFi Connect and the accessory has been established.
- LED flashes (1x / second): The network has not been configured.
- LED flashes (2x / second): Attempting to establish a wireless connection.
- The LED lights up on an alternating basis for 5 sec. and pauses for 1 sec.: WiFi Connect cannot establish a connection.

Connecting to other devices

WiFi Connect can be used for various accessories with wireless capabilities (e.g. Cool Control) and J.O.E.®.

- ▶ Switch on the accessory and the coffee machine.

If a device is switched off and then on again, the wireless connection is re-established automatically.

i Your WiFi Connect must also be activated in your automatic coffee machine. You can do this in the machine settings. Find out more at jura.com/wifi.

i If several machines with Cool Control are connected to the wireless network, the machine with the strongest signal is addressed.

Resetting WiFi Connect (and/or security PIN) to factory setting

If you experience any general problems with the WiFi Connect (e.g. a connection problem), it can be reset to the factory setting.

- ▶ Connect WiFi Connect to your Cool Control.
- ▶ Press and hold the off button for 3 seconds.

i WiFi Connect will also be reset if you reset your automatic coffee machine to the factory settings while WiFi Connect is connected.

i WiFi Connect will also be reset if you disconnect the connection to WiFi Connect in the machine settings for your automatic coffee machine.

This device complies with Industry Canada licence-exempt RSS standard(s) and part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

JURA International Headquarters, Switzerland

Homepage: jura.com
Phone number: +41 62 389 82 33
Fax: +41 62 389 81 37
E-Mail: export@jura.com
Address: JURA Elektorapparate AG
Kaffeeweltstrasse 10
4626 Niederbuchsiten
Switzerland

