

jura®



Smart Connect

Instructions for use

Proper use

The Smart Connect may only be used with specified JURA coffee machines. It provides wireless communication between the coffee machine and various accessories (for compatible devices see www.jura.com). Use for any other purpose will be deemed improper. JURA cannot accept any responsibility for the consequences of improper use.

Smart Connect at a glance



- 1 LED: Indicates the status of the Smart Connect
- 2 Reset button: To connect the Smart Connect with other wireless-enabled accessories
- 3 Connector: Inserted into the service socket on the coffee machine

Installation

The Smart Connect must be inserted into the coffee machine's service socket. This is usually on the top or back of the machine, beneath a removable cover. If you don't know where the service socket of your coffee machine is, ask your dealer or visit www.jura.com.

- ▶ Plug the Smart Connect into the coffee machine's service socket.

The Smart Connect switches on automatically.

For operation, the accessory must be no more than 3 m away from the coffee machine.

A frequency band of 2.4 GHz is used for this wireless connection. In this case, the maximum transmission power is below 1 mW.

LED indicators

- LED does not light up: The coffee machine is switched off; the Smart Connect is not being supplied with power.
- LED lights up: The wireless connection between the Smart Connect and the accessory has been established.
- LED flashes (1x / second): Attempting to establish a wireless connection.

Connecting to other devices

The Smart Connect can be used for various wireless-enabled accessories (e.g. Cool Control Wireless / Smart Compact Payment Box).

- ▶ Position the accessory near the coffee machine (a maximum of 0.5 m away).
- ▶ Switch on the accessory and the coffee machine.
- ▶ Press the reset button of the Smart Connect (e.g. with a paper clip).
- ▶ Then (within 30 sec.) press **and hold** the reset key of the accessory until the LED lights up to indicate the successful connection.

If a device is switched off and then on again, the wireless connection is re-established automatically.

i Some JURA coffee machines have an automatic connection function (see operating instructions for the specific machine).

Resetting Smart Connect (and/or security PIN) to factory setting

If you experience any general problems with the Smart Connect (e.g. a connection problem), it can be reset to the factory setting.

- ▶ Press the reset button of the Smart Connect for around 5 seconds.
The LED flashes 5 times to confirm the reset.

This device complies with Industry Canada licence-exempt RSS standard(s) and part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

We confirm that JURA Smart Connect (Art. 72167) complies with Directive 2014/53/EU. The complete Declaration of Conformity can be accessed at www.jura.com/conformity.

JURA International Headquarters, Switzerland

Homepage: www.jura.com
Phone number: +41 62 389 82 33
Fax: +41 62 389 81 37
E-Mail: export@jura.com
Address: JURA Elektorapparate AG
Kaffeeweltstrasse 10
4626 Niederbuchsiten
Switzerland

